

TZIDC, TZIDC-200 Digital Positioner



Short product description

Digital positioner for the positioning of pneumatically controlled actuators.

Device firmware version: 05.00.00

Further information

Additional documentation on TZIDC, TZIDC-200 is available to download free of charge at www.abb.com/positioners.

Alternatively simply scan this code:



Manufacturer

ABB Automation Products GmbH

Process Automation

Schillerstr. 72

32425 Minden

Germany

Tel: +49 571 830-0

Fax: +49 571 830-1806

Customer service center

Tel: +49 180 5 222 580

Mail: automation.service@de.abb.com

Contents

1	Safety.....	5			
1.1	General information and instructions	5			
1.2	Warnings	5			
1.3	Intended use.....	5			
1.4	Improper use	5			
1.5	Warranty provisions	5			
2	Operation.....	6			
2.1	Safety instructions	6			
2.2	Parameterization of the device	6			
2.2.1	Menu navigation	6			
2.3	Menu levels.....	7			
2.4	Operating modes.....	7			
2.4.1	Operating mode 1.0: Control with adaptation.....	7			
2.4.2	Operating mode 1.1: Control without adaptation..	7			
2.4.3	Operating mode 1.2: Manual adjustment in the stroke range	8			
2.4.4	Operating mode 1.3: Manual adjustment in the sensor range.....	8			
2.5	Inhibiting operation	8			
3	Configuration.....	9			
3.1	General information.....	9			
3.2	Example	9			
3.3	HART parameter description.....	10			
3.4	HART parameter overview (graphic)	12			
3.5	Parameter group 1: Standard	12			
3.5.1	ACTUATOR – Actuator type.....	12			
3.5.2	AUTO_ADJ – automatic adjustment	12			
3.5.3	ADJ_MODE – Automatic adjustment mode.....	13			
3.5.4	TEST – Test.....	14			
3.5.5	FIND_DEV – Find device	14			
3.5.6	EXIT – Return to operating level	14			
3.6	Parameter group 2: Setpoint.....	15			
3.6.1	MIN_RGE – Setpoint range min.	15			
3.6.2	MAX_RGE – Setpoint range max.....	15			
3.6.3	CHARACT – Characteristic curve.....	15			
3.6.4	ACTION – Direction of action (setpoint signal).....	15			
3.6.5	SHUT_CLS – Shut-off value 0%.....	16			
3.6.6	SHUT-OPN – Shut-off value 100%.....	16			
3.6.7	RAMP UP – Setpoint ramp (up).....	16			
3.6.8	RAMP DN – Setpoint ramp (down).....	16			
3.6.9	EXIT – Return to operating level	17			
3.7	Parameter group 3: Operating range.....	17			
3.7.1	MIN_RGE – Operating range min.	17			
3.7.2	MAX_RGE – Operating range max.	17			
3.7.3	ZERO_POS – Zero position.....	18			
3.7.4	EXIT – Return to operating level	18			
3.8	Parameter group 4: Messages	18			
3.8.1	TIME_OUT – Dead band time limit.....	18			
3.8.2	POS_SW1 – Switching point SW1	18			
3.8.3	POS_SW2 – Switching point SW2	19			
3.8.4	SW1_ACTV – Active direction SW1	19			
3.8.5	SW2_ACTV – Active direction SW2.....	19			
3.8.6	EXIT – Return to operating level.....	19			
3.9	Parameter group 5: Alarms	20			
3.9.1	LEAKAGE – Leakage at actuator.....	20			
3.9.2	SP_RGE – Setpoint monitoring	20			
3.9.3	SENS_RGE – Operating range exceeded.....	20			
3.9.4	CTRLER – Controller inactive	20			
3.9.5	TIME_OUT – Dead band time limit.....	20			
3.9.6	STRK_CTR – Movement counter	20			
3.9.7	TRAVEL – Travel counter	21			
3.9.8	EXIT – Return to operating level.....	21			
3.10	Parameter group 6: Manual adjustment	21			
3.10.1	MIN_VR – Operating range min.	21			
3.10.2	MAX_VR – Operating range max.	22			
3.10.3	ACTUATOR – Actuator type.....	22			
3.10.4	SPRNG_Y2 – Spring action (Y2).....	22			
3.10.5	DANG_DN – Dead Angle Close.....	23			
3.10.6	DANG_UP – Dead Angle Open	23			
3.10.7	BOLT_POS – Actuator position	23			
3.10.8	EXIT – Return to operating level.....	23			
3.11	Parameter group 7: Control parameters	24			
3.11.1	KP UP – KP value (up)	24			
3.11.2	KP DN – KP value (down).....	24			
3.11.3	TV UP – TV value (up)	24			
3.11.4	TV DN – TV value (down)	25			
3.11.5	Y-OFS UP – Y offset (up).....	25			
3.11.6	Y-OFS DN – Offset (down)	25			
3.11.7	TOL_BAND – Tolerance band	26			
3.11.8	DEADBAND – Dead band	26			
3.11.9	DB_APPR – Dead band approach	26			
3.11.10	DB_CALC – Dead-band determination.....	26			
3.11.11	LEAK_SEN – Leakage sensitivity	27			
3.11.12	EXIT – Return to operating level.....	27			
3.12	Parameter group 8: Analog output	27			
3.12.1	MIN_RGE – Current range min.	27			
3.12.2	MAX_RGE – Current range max.	27			
3.12.3	ACTION – Characteristic curve action	27			
3.12.4	ALARM – Alarm	28			
3.12.5	RB_CHAR – Count back characteristic curve.....	28			
3.12.6	TEST – Test	28			
3.12.7	ALR_ENAB – Alarm via analog output	28			
3.12.8	CLIPPING – Extending the signal output range... 28				
3.12.9	EXIT – Return to operating level.....	28			

3.13	Parameter group 9: digital output.....	29
3.13.1	ALRM_LOG – Alarm output logic	29
3.13.2	SW1_LOG – Logic.....	29
3.13.3	SW2_LOG – Logic.....	29
3.13.4	EXIT – Return to operating level	29
3.14	Parameter group 10: digital input	30
3.14.1	FUNCTION – Digital input function selection.....	30
3.14.2	EXIT – Return to operating level	30
3.15	Parameter group 11: Safe position.....	31
3.15.1	FAIL_POS – Safe position	31
3.15.2	FACT_SET – Factory setting	31
3.15.3	IP-TYP – Type of the I/P module	32
3.15.4	IP_COMP – IP Compensation	32
3.15.5	HART_REV – HART version	32
3.15.6	EXIT – Return to operating level	32
4	Diagnosis / error messages	33
4.1	Error codes.....	33
4.2	Alarm codes	35
4.3	Message codes	36
4.4	Error handling	37
4.4.1	Positioner vibrates	37
4.4.2	Positioner without function.....	38

1 Safety

1.1 General information and instructions

These instructions are an important part of the product and must be retained for future reference.

Installation, commissioning, and maintenance of the product may only be performed by trained specialist personnel who have been authorized by the plant operator accordingly. The specialist personnel must have read and understood the manual and must comply with its instructions.

For additional information or if specific problems occur that are not discussed in these instructions, contact the manufacturer.

The content of these instructions is neither part of nor an amendment to any previous or existing agreement, promise or legal relationship.

Modifications and repairs to the product may only be performed if expressly permitted by these instructions.

Information and symbols on the product must be observed. These may not be removed and must be fully legible at all times.

The operating company must strictly observe the applicable national regulations relating to the installation, function testing, repair and maintenance of electrical products.

1.2 Warnings

The warnings in these instructions are structured as follows:

DANGER

The signal word "DANGER" indicates an imminent danger. Failure to observe this information will result in death or severe injury.

WARNING

The signal word "WARNING" indicates an imminent danger. Failure to observe this information may result in death or severe injury.

CAUTION

The signal word "CAUTION" indicates an imminent danger. Failure to observe this information may result in minor or moderate injury.

NOTE

The signal word "NOTE" indicates useful or important information about the product.

The signal word "NOTE" is not a signal word indicating a danger to personnel. The signal word "NOTE" can also refer to material damage.

1.3 Intended use

Positioning of pneumatically controlled actuators; designed for mounting on linear and part-turn actuators.

The device is designed for use exclusively within the stated values on the name plate and in the data sheet.

- The maximum operating temperature must not be exceeded.
- The permissible ambient temperature must not be exceeded.
- The housing protection type must be observed.

1.4 Improper use

The following are considered to be instances of improper use of the device:

- For use as a climbing aid, e.g. for mounting purposes
- For use as a support for external loads, e.g. as a support for piping, etc.
- Material application, e.g. by painting over the name plate or welding/soldering on parts.
- Material removal, e.g. by spot drilling the housing.

1.5 Warranty provisions

Using the device in a manner that does not fall within the scope of its intended use, disregarding this manual, using underqualified personnel, or making unauthorized alterations releases the manufacturer from liability for any resulting damage. This renders the manufacturer's warranty null and void.

2 Operation

2.1 Safety instructions

⚠ CAUTION

Risk of injury due to incorrect parameter values!

Incorrect parameter values can cause the valve to move unexpectedly. This can lead to process failures and result in injuries.

- Before recommissioning a positioner that was previously in use at another location, always reset the device to its factory settings.
- Never start Auto Adjust before restoring the factory settings.

If there is a chance that safe operation is no longer possible, take the device out of operation and secure it against unintended startup.

2.2 Parameterization of the device

The LCD display features operating buttons which enable the device to be operated with the housing cover open.

2.2.1 Menu navigation




Fig. 1: LCD display with operating buttons

- ① Value display with unit ② Symbol display
③ Designator display ④ Operating buttons for menu navigation

Value display with unit

This 7-segment display with four digits indicates parameter values or parameter reference numbers. For values, the physical unit (°C, %, mA) is also displayed.

Designator display

This 14-segment display with eight digits indicates the designators of the parameters with their status, of the parameter groups, and of the operating modes.

Description of symbols

Symbol	Description
	Operation or access is restricted.
	Control loop is active. The symbol is displayed when the positioner is in operating mode 1.0 CTRL_ADP (adaptive control) or 1.1 CTRL_FIX (fixed control) at operating level. On the configuration level there are test functions for which the controller will be active as well. The control loop symbol will also be displayed when these functions are active.
	Manual adjustment. The symbol is displayed when the positioner is in operating mode 1.2 MANUAL (manual adjustment within the stroke range) or 1.3 MAN_SENS (manual adjustment within the measuring range) at operating level. At configuration level, manual adjustment is active when setting the valve range limits (parameter group 6 MIN_VR (min. of valve range) and 6 MAX_VR (max. of valve range)). The symbol will also be displayed when these parameters are being set.
conf	The configuration icon indicates that the positioner is at the configuration level. The control operation is inactive.

The four operating buttons **ENTER**, **MODE**, **↑** and **↓** are pressed individually or in certain combinations according to the function desired.

Operating button functions

Control button	Meaning
ENTER	<ul style="list-style-type: none"> – Acknowledge message – Start an action – Save in the non-volatile memory
MODE	<ul style="list-style-type: none"> – Choose operating mode (operating level) – Select parameter group or parameter (configuration level)
↑	UP direction button
↓	DOWN direction button
Press and hold all four buttons for 5 s	Reset

2.3 Menu levels

The positioner has two operating levels:

Operating level	On the operating level the positioner operates in one of four possible operating modes (two for automatic control and two for manual mode). Parameters cannot be changed or saved on this level.
Configuration level	On this level most of the parameters of the positioner can be changed locally. The PC is required to change the limit values for the movement counter, the travel counter, and the user-defined characteristic curve. On the configuration level the active operating mode is deactivated. The I/P module is in neutral position. The control operation is inactive.

i NOTE

Property damage

During external configuration via a PC, the positioner no longer responds to the setpoint current. This may lead to process failures. Prior to external configuration, always move the actuator to the safety position and activate manual adjustment.

2.4 Operating modes


2.4.1 Operating mode 1.0: Control with adaptation



Controlling operation with automatic adaptation of the control parameters

When the **P1.0CTRL_ADP** positioner is operated in "Adaptive Mode", the control parameters are automatically optimized to the operating conditions in small increments. This is especially helpful if valves and fittings could not be operated with reference conditions while the Auto Adjust function was in progress.

Since self-optimization in "Adaptive Mode" is subject to several factors during operation and mismatches could result over a longer period, we recommend that this operating mode only be activated over several hours and be followed by the mode **P1.1 CTRL_FIX**.



The valve position is indicated as a percentage of the operating range (from 0 ... 100%).

2.4.2 Operating mode 1.1: Control without adaptation



Controlling operation with fixed parameters

This is the normal recommended operating mode.



In contrast to the operating mode **P1.0 CTRL_ADP**, the control parameters are not automatically adjusted. The valve position is indicated as a percentage of the operating range (from 0 ... 100%).

In both control modes **1.0** and **1.1**, several values can be displayed besides the current actuator position:

Setpoint display



1. Press and hold the **▲** button.
The setpoint is displayed.
2. Briefly press **ENTER**.

The setpoint display is toggled between the setpoint current at the input terminals in mA and the setpoint as a percentage of the stroke range.

Temperature display



1. Press and hold the **▼** button.
The temperature inside the case is displayed.
2. Briefly press **ENTER**.
3. The temperature display is toggled between °C and °F.

Display of control deviation



1. Press and hold the **▲** and **▼** button.

The control deviation is displayed as a percentage (%) of the stroke range.

2.4.3 Operating mode 1.2: Manual adjustment in the stroke range



The valve is adjusted manually using the direction buttons **↑** and **↓** within the stroke range.

1. Press and hold the button for the desired direction.
2. To activate the high speed mode in the manual mode, press the second arrow button.

⚠ CAUTION

If air escapes due to a leakage, the position will not be readjusted.

Configured stroke limit positions and stroke times are not effective in manual mode.



In this operating mode the valve position is indicated as a percentage (%) of the stroke range.

2.4.4 Operating mode 1.3: Manual adjustment in the sensor range



See operating mode 1.2



Unlike step 1.2, this operating mode is used to determine whether the available detection range of the position sensor is used correctly after mounting the positioner to the actuator. In this mode, the valve position is indicated in angular degrees with respect to the sensor range (i.e., 0 ... 140 °).

2.5 Inhibiting operation

Positioner operation can be inhibited completely or partially via the digital input and the **FUNCTION** parameter in parameter group 10 (**DIG_IN** (digital input)).

This allows the user to prevent or restrict operating actions of unauthorized personnel as desired. When operation is disabled in this way, the key symbol is indicated in the display.

The following levels of configuration locks are possible:

Inhibiting the local configuration

Local operation on the operating level and remote operation and configuration via a PC are still possible.

Inhibiting all local operating functions

No local operating actions can be executed. Both the operating level and the configuration level are locked. Remote operation and setting of parameters via a PC is still possible.

Inhibiting local operation and remote configuration

It is not possible to operate or configure the positioner locally or configure it using a PC.

i NOTE

This inhibit function can only be deactivated when a voltage of 12 ... 24 V is applied at the digital input of the positioner (see Function selection in parameter group 10 on page 30).

3 Configuration

3.1 General information

Most parameters for the positioner can be set locally, meaning that configuration only needs to be performed via the local communication interface (LCI) or FSK modem and PC in exceptional cases.

You may also deny or restrict local modification and saving of parameters by completely or partially blocking access to the configuration level (see Chapter "Inhibiting operation" on page 8 and the description of the **Function** parameter on page 30).

To simplify the process, the different parameters are grouped as follows:

3.2 Example



Parameter (1st line in display)	Indicator (2nd line in display)	Function	Possible parameter settings	Unit	Factory Setting
P1._	STANDARD				
P1.0	ACTUATOR	Actuator type	LINEAR, ROTARY	-	LINEAR
P1.1	AUTO_ADJ	Autoadjust	Command / Function is being run	-	-
P1.2	ADJ_MODE	Automatic adjustment mode	FULL, STROKE, CTRL, PAR, ZERO_POS, LOCKED	-	FULL
P1.3	TEST	Test	Command / Function is being run	-	INACTIV
P1.4	EXIT	Return to operating level	Command / Function is being run	-	NV_SAVE
P2._	SETPOINT				

ID	Designator	Name
P1._	STANDARD	Standard
P2._	SETPOINT	Setpoint
P3._	ACTUATOR	Actuator
P4._	MESSAGES	Events
P5._	ALARMS	Alarms
P6._	MAN_ADJ	Manual adjustment
P7._	CTRL_PAR	Control parameters
P8._	ANLG_OUT	Analog output
P9._	DIG_OUT	Digital output
P10._	DIG_IN	Digital input
P11._	FS / IP	Factory setting, I/P type

The following sections provide an overview (in tabular and graphical format) of the overall structure of the parameter groups and parameters.


3.3 HART parameter description

Parameter	Display	Function		Possible parameter setting	Unit	Factory setting
P1_	STANDARD					
P1.0	ACTUATOR	Actuator type	Actuator type	LINEAR, ROTARY	---	LINEAR
P1.1	AUTO_ADJ	Auto adjust	Autoadjust	Function	---	---
P1.2	ADJ_MODE	Auto adjust mode	Automatic adjustment mode	FULL,STROKE,CTRL_PAR, ZERO_POS, LOCKED		FULL
P1.3	TEST	Test	Test	Function	---	INACTIVE
P1.4	FIND_DEV	Find device	Find device	DISABLE, ONE TIME, CONTINUOUS	---	DISABLE
P1.5	EXIT	Return	Return to operating level	Function	---	NV_SAVE
P2_	SETPOINT					
P2.0	MIN_RGE	Min setpoint range	Min. setpoint range	4.0 ... 18.4	mA	4.0
P2.1	MAX_RGE	Max setpoint range	Max. setpoint range	20.0 ... 5.6	mA	20.0
P2.2	CHARACT	Charact. curve	Characteristic curve	LINEAR, 1:25, 1:50, 25:1, 50:1, USERD	---	LINEAR
P2.3	ACTION	Valve action	Effective direction	DIRECT, REVERSE	---	DIRECT
P2.4	SHUT_CLS	Shut-off value 0%	Shut-off value 0 %	OFF, 0.1 ... 45.0	%	1.0
P2.5	SHUT_OPN	Shut off value 100%	Shut-off value 100 %	55.0 ... 100.0, OFF	%	OFF
P2.6	RAMP UP	Set point ramp, up	Setpoint ramp (up)	OFF, 0 ... 200	---	OFF
P2.7	RAMP DN	Set point ramp, down	Setpoint ramp (down)	OFF, 0 ... 200	---	OFF
P2.8	EXIT	Return	Return to operating level	Function	---	NV_SAVE
P3_	ACTUATOR					
P3.0	MIN_RGE	Min. of stroke range	Operating range, min.	0.0 ... 90.0	%	0.0
P3.1	MAX_RGE	Max. of stroke range	Operating range, max.	100.0 ... 10.0	%	100
P3.2	ZERO_POS	Zero position	Zero position	CLOCKWISE, CTCLOCKWISE	---	CTCLOCKWISE
P3.3	EXIT	Return	Return to operating level	Function	---	NV_SAVE
P4_	MESSAGES					
P4.0	TIME_OUT	Control time out	Dead band time limit	OFF, ... 200	---	OFF
P4.1	POS_SW1	Position switch 1	Switching point SW1	0.0 ... 100.0	%	0.0
P4.2	POS_SW2	Position switch 2	Switching point SW2	0.0 ... 100.0	%	100.0
P4.3	SW1_ACTV	Switchpoint 1 enable	Active direction SW1	FALL_BEL, EXCEED	---	FALL_BEL
P4.4	SW2_ACTV	Switchpoint 2 enable	Active direction SW2	FALL_BEL, EXCEED	---	EXCEED
P4.5	EXIT	Return	Return to operating level	Function	---	NV_SAVE
P5_	ALARMS					
P5.0	LEAKAGE	Leakage detection	Leakage to actuator	ACTIVE, INACTIVE	---	INACTIVE
P5.1	SP_RGE	Setpoint rng monitor	Outside the setpoint range	ACTIVE, INACTIVE	---	INACTIVE
P5.2	SENS_RGE	Sens. range monitor	Operating range exceeded	ACTIVE, INACTIVE	---	INACTIVE
P5.3	CTRLER	Controller monitor	Controller inactive	ACTIVE, INACTIVE	---	INACTIVE
P5.4	TIME_OUT	Control time out	Dead band time limit	ACTIVE, INACTIVE	---	INACTIVE
P5.5	STRK_CTR	Stroke counter	Movement counter	ACTIVE, INACTIVE	---	INACTIVE
P5.6	TRAVEL	Travel counter	Travel counter	ACTIVE, INACTIVE	---	INACTIVE
P5.7	EXIT	Return	Return to operating level	Function	---	NV_SAVE
P6_	MAN_ADJ					
P6.0	MIN_VR	Min. valve range	Operating range, min.	0.0 ... 100.0	%	0
P6.1	MAX_VR	Max. valve range	Operating range, max.	0.0 ... 100.0	%	100
P6.2	ACTUATOR	Actuator type	Actuator type	LINEAR, ROTARY	---	LINEAR
P6.3	SPRNG_Y2	Spring action (Y2)	Spring action (Y2)	CLOCKWISE, CTCLOCKWISE	---	CTCLOCKWISE
P6.4	DANG_DN	Dead angle close	Dead angle 0 %	0.0 ... 45.0	%	0.0
P6.5	DANG_UP	Dead angle open	Dead angle 100 %	55.0 ... 100.0	%	100.0
P6.6	BOLT_POS	Bolt position	Actuator position	LEVER, STEM	---	LEVER
P6.7	EXIT	Return	Return to operating level	Function	---	NV_SAVE

Parameter	Display	Function	Possible parameter setting	Unit	Factory setting
P7._	CTRL_PAR				
P7.0	KP UP	KP value, up	KP value (up)	0.1 ... 120.0	--- 5.0
P7.1	KP DN	KP value, down	KP value (down)	0.1 ... 120.0	--- 5.0
P7.2	TV UP	TV value, up	TV value (up)	10 ... 450	--- 200
P7.3	TV DN	TV value, down	TV value (down)	10 ... 450	--- 200
P7.4	Y-OFS UP	Y offset, up	Y offset (up)	0.0 ... 100.0	% 48.0
P7.5	Y-OFS DN	Y offset, down	Y offset (down)	0.0 ... 100.0	% 48.0
P7.6	TOL_BAND	Tolerance band (zone)	Tolerance band (zone)	0.3 ... 10.0	% 1.5
P7.7	DEADBAND	Deadband	Dead band	0.10 ... 10.00	% 0.10
P7.8	DB_APPR	Deadband Approach	Dead-band approach	SLOW, MEDIUM, FAST	
P7.9	TEST	Test	Test	Function	--- INACTIVE
P7.10	DB_CALC	Deadband calculat.	Dead-band determination	ON, OFF	--- ON
P7.11	LEAK_SEN	Leakage sensivity	Leakage sensitivity	1 ... 7200	S 30
P7.12	CLOSE_UP	Pos. time out	Position monitoring	0.0 ... 100.0	% 30.0
P7.13	EXIT	Return	Return to operating level	Function	--- NV_SAVE
P8._	ANLG_OUT				
P8.0	MIN_RGE	Min. range	Min. current range	4.0 ... 18.4	mA 4.0
P8.1	MAX_RGE	Max. range	Max. current range	20.0 ... 5.7	mA 20.0
P8.2	ACTION	Action	Direction of action of characteristic curve	DIRECT, REVERSE	--- DIRECT
P8.3	ALARM	Alarm current	Alarm message	HIGH_CUR, LOW_CUR	--- HIGH_CUR
P8.4	RB_CHAR	Readback character.	Converted characters	DIRECT, RECALC	DIRECT
P8.5	TEST	Test	Test	Function	--- NONE
P8.6	ALR_ENAB	Alarm function enabled	Alarm via analog output	ON, OFF	--- ON
P8.7	CLIPPING	Current signal Signal clipping range	Extension of signal output to 3.8 ... 20.5 mA	4.0 ... 20.0; 3.8 ... 20.5 mA	mA 4.0 ... 20.5
P8.8	EXIT	Return	Return to operating level	Function	--- ---
P9._	DIG_OUT				
P9.0	ALRM_LOG	Alarm logic	Alarm output logic	ACTIVE_HI, ACTIVE_LO	--- ACTIVE_HI
P9.1	SW1_LOG	Switchpoint 1 logic	Logic SW1	ACTIVE_HI, ACTIVE_LO	--- ACTIVE_HI
P9.2	SW2_LOG	Switchpoint 2 logic	Logic SW2	ACTIVE_HI, ACTIVE_LO	--- ACTIVE_HI
P9.3	TEST	Test	Test	Function	--- NONE
P9.4	EXIT	Return	Return to operating level	Function	--- NV_SAVE
P10._	DIG_IN				
P10.0	FUNCTION	Function select	Function selection	NONE, POS_0 %, POS_100 %, POS_HOLD	--- NONE
P10.1	EXIT	Return	Return to operating level	Function	--- ---
P11._	FS / IP				
P11.0	FAIL_POS	Save position	Safe position	ACTIVE, INACTIVE	--- INACTIVE
P11.1	FACT_SET	Factory setting	Factory Setting	Function	--- START
P11.2	IP-TYP	I/P module type	Type of I/P module	NO_F_POS, F_SAFE_1, F_SAFE_2, F_FREEZE1, F_FREEZE2	--- [CUSTOM]
P11.3 ¹⁾	IP_COMP	IP compensation	IP compensation	ON, OFF	--- ON
P11.4	HART_REV	HART revision	HART Revision	5; 7	--- 5
P11.5	EXIT	Return	Return to operating level	Function	--- NV_SAVE

1) Activation only by ABB Service

3.4 HART parameter overview (graphic)



M10487

Fig. 2

3.5 Parametergroup 1: Standard



3.5.1 ACTUATOR – Actuator type



With this parameter you can configure the positioner for operation on a linear actuator (sensor range $\pm 30^\circ$) or on a part-turn actuator (sensor range $\pm 45^\circ$). No mechanical modifications to the positioner are required.

i NOTE

After changing the actuator type, it is recommended that you run automatic adjustment to prevent linearity errors.

Selection

LINEAR	Linear actuator
ROTARY	Part-turn actuator

3.5.2 AUTO_ADJ – automatic adjustment



The following values are determined during Auto Adjust:

- Direction of action of the actuator
- Direction of action of the reset spring
- Actuator travel of the multi-turn actuator / final control element
- Stroke time for both directions
- Control parameters
- Offset for the I/P module

i NOTE

The mode and scope of the automatic adjustment function can be selected using parameter **ADJ_MODE**.

To start the automatic adjustment, press and hold **ENTER** until the countdown from 3 to 0 is finished. During the countdown, the automatic adjustment mode selected using parameter **ADJ_MODE** is shown on the display. While Autoadjust is running, the control loop symbol flashes in the display, and the current state of Autoadjust is indicated with the messages listed below.



(No acknowledgment)

i NOTE

All messages except "RUN" must be acknowledged with **ENTER**.



(Acknowledgment required)

RUN	Autoadjust is running.
CALC_ERR	Error during plausibility check.
COMPLETE	Autoadjust completed successfully.
BREAK	Autoadjust has been stopped by the operator. This can be done locally by pressing ENTER .
OUTOFRNG	Sensor range of the positioner has been exceeded; Autoadjust was stopped.
NO_SCALE	End positions have not yet been determined; therefore, partial Autoadjust cannot be run
RNG_ERR	Less than 10% of the sensor range is used.
TIMEOUT	Timeout. The control parameters could not be determined within 200 seconds. Automatic adjustment was stopped.
SPR_ERR	The actual spring action does not match the configured spring action

Once Autoadjust has finished running without encountering any errors, the device displays the message "RUN" in the bottom line and a code number in the top line, indicating the step that is currently being executed:

10	Air is completely evacuated from actuator (OUT1). The fully evacuated position is saved.
20	Air is completely ventilated from actuator (OUT1). The fully ventilated position is saved.
30	Determining stroke time is prepared.
31	Actuator travels from 0% to 100%, stroke time is measured and saved.
32	Actuator travels from 100% to 0%, stroke time is measured and saved.
40 - 49	Tolerance band is determined and saved (minimum value). PD parameters for fast control < tolerance band is determined and saved.
50 - 59	PID parameters for fast control < tolerance band is determined and saved.
200	Automatic adjustment is complete.

If a partial run of automatic adjustment has been selected (see parameter **DANG_DN** on page 23), the following code numbers are shown:

Stops only	Steps 10 ... 32 and step 200
Parameters only	Steps 40 ... 120 and step 200
Zero only:	
10	Air is completely evacuated from actuator (OUT1). The fully evacuated position is saved.
200	Automatic adjustment is complete.

3.5.3 ADJ_MODE – Automatic adjustment mode



Use this parameter to define the mode or scope of the Auto Adjust function.

FULL	Complete Autoadjust
STROKE	Stops only
CTRL_PAR	Control parameters only
ZERO_POS	Zero position only (configured stops required)
LOCKED	No Autoadjust

3.5.4 TEST – Test



The test is used to activate the positioner, and you can check the effects of the changes to this parameter group, e.g., by introducing setpoint changes or setpoint ramps using a current source.

Normally, **INACTIVE** is shown in the display. To start the test, press and hold **ENTER** until the countdown from 3 to 0 is finished. The test is activated. The display shows the control loop symbol and a flashing message. The test is automatically stopped after two minutes and can also be stopped by pressing any button.

i NOTE

It is not possible to start the test when the safe position is active (see the **FAIL_POS** parameter on page 31.) Instead, the message **FAIL_POS** is displayed.

3.5.5 FIND_DEV – Find device



This function is only possible with HART 7 and enables identification of the affected device in the system. Following activation, the device sends a signal on request under HART 7. The following signals are available:

- Disable
- One time
- Continuous

3.5.6 EXIT – Return to operating level



With this parameter you can leave the configuration level. The positioner returns to the operating level. Here you can either save data in the non-volatile memory or discard all previously made changes (also the changes in other parameter groups).

To leave the configuration level (with or without saving), press and hold **ENTER** until the countdown from 3 to 0 is finished.

The active saving process is indicated by the message **NV_SAVE**. After saving a plausibility check is executed.

If an error occurs during the check or while saving, the data cannot be saved and an error message is displayed instead (see Chapter "Error codes" on page 33).

Selection

NV_SAVE	Saves settings in the non-volatile memory.
CANCEL	Discards all changes made since the last permanent save operation.

3.6 Parameter group 2: Setpoint



3.6.1 MIN_RGE – Setpoint range min.



The setpoint range is the input current range as a percentage of the working range for the valves and fittings (from 0 ... 100 %).

i NOTE

The configured setpoint range must not be smaller than 20 % (3.2 mA).

Use the **MIN_RGE** parameter to determine the lower limit of the setpoint range. You can enter a value within the admissible value range of 4 ... 18.4 mA, with one decimal.

3.6.2 MAX_RGE – Setpoint range max.



The setpoint range is the input current range as a percentage of the working range for the valves and fittings (from 0 ... 100 %).

i NOTE

The configured setpoint range must not be smaller than 20 % (3.2 mA).

Use the **MAX_RGE** parameter to determine the upper limit of the setpoint range. You can enter a value within the admissible value range of 5.6 ... 20 mA, with one decimal.

Setting examples

Setpoint Range	Min. = 8.3 mA, Max. = 15.6 mA
Split range configuration between	Min. = 12.0 mA, Max. = 20.0 mA

3.6.3 CHARACT – Characteristic curve



Use this parameter to select a function that adjusts the behavior of the positioner to the analog input signal according to a predefined course.

This linearizes the characteristic curves for the valves and fittings and improves the behavior of the overall control loop.

In addition to five predefined characteristic curves, you can also select a user-configurable characteristic curve, which can only be generated and saved in the device via a PC with the appropriate configuration program (and not locally).

Selection

LINEAR	Linear
EP 1/25	equal percentage 1:25
EP 1/50	equal percentage 1:50
EP 25/1	equal percentage 25:1
EP 50/1	equal percentage 50:1
USERDEF	configurable by user
USERDEF	LINEAR

3.6.4 ACTION – Direction of action (setpoint signal)



The direction of action describes the relationship between the analog setpoint and pneumatic output **OUT1**.

Increasing	Setpoint 0 ... 100 % → Output 0 ... 100 %
Decreasing	Setpoint 0 ... 100 % → Output 100 ... 0 %

Selection


DIRECT	Increasing Control signal 4 ... 20 mA, and setpoint 0 ... 100 % = position 0 ... 100 %
REVERSE	Decreasing Control signal 20 ... 4 mA, and setpoint 100 ... 0 % = position 0 ... 100 %

3.6.5 SHUT_CLS – Shut-off value 0%



The shut-off value **SHUT_CLS** is a percentage of the operating range (with one decimal place) from which the 0 % position is approached. Once the specified position limit value is reached, the actuator moves into the 0% end position. As a result, the valve is moved in control mode into the mechanical 0% end position through full evacuation or ventilation.
In the 0 % end position, it continues to be adjusted to the position setpoint.

3.6.6 SHUT-OPN – Shut-off value 100%



The shut-off value **SHUT_OPN** is a percentage of the operating range (with one decimal place) from which the 100 % position is approached. Once the specified position limit value is reached, the actuator moves into the 100% mechanical end position.
In the 100 % end position, it continues to be adjusted to the position setpoint.
When entering a value, the valve is moved in control mode into the mechanical 100% end position through full evacuation or ventilation.

Settings for Autoadjust:

Rotary actuators = 99	When the limit value is reached, the actuator is fully ventilated.
Linear actuators = 100	Controlling continues in the 100% position.

3.6.7 RAMP UP – Setpoint ramp (up)



Here the stroke time for the actuator can be increased. A setpoint change is not directly transferred to the positioner; instead, the speed is reduced accordingly. The set value should always be greater than the shortest stroke time determined during auto adjust.

i NOTE

To display the stroke time (stroke time up), press and hold the **ENTER** button.



! CAUTION

The setpoint ramp is deactivated in the case of any functions which involve approaching the safe position. This even applies in the case of errors.
The actuator will therefore move without delay.
— Do not reach into the adjustment mechanism.

3.6.8 RAMP DN – Setpoint ramp (down)



Here the stroke time for the actuator can be increased. A setpoint change is not directly transferred to the positioner; instead, the speed is reduced accordingly. The set value should always be greater than the shortest stroke time determined during auto adjust.

i NOTE

To display the stroke time (stroke time up), press and hold the **ENTER** button.



! CAUTION

The setpoint ramp is deactivated in the case of any functions which involve approaching the safe position. This even applies in the case of errors.
The actuator will therefore move without delay.
— Do not reach into the adjustment mechanism.

3.6.9 EXIT – Return to operating level



With this parameter you can leave the configuration level. The positioner returns to the operating level. Here you can either save data in the non-volatile memory or discard all previously made changes (also the changes in other parameter groups).

To leave the configuration level (with or without saving), press and hold **ENTER** until the countdown from 3 to 0 is finished.

The active saving process is indicated by the message **NV_SAVE**. After saving a plausibility check is executed.

If an error occurs during the check or while saving, the data cannot be saved and an error message is displayed instead (see Chapter "Error codes" on page 33).

Selection	
NV_SAVE	Saves settings in the non-volatile memory.
CANCEL	Discards all changes made since the last permanent save operation.

3.7 Parameter group 3: Operating range



3.7.1 MIN_RGE – Operating range min.



The working range can be configured to be smaller than the maximum mechanical working range.

The setpoint range always refers to the configured working range. Use this parameter to specify the lower limit of the operating range.

CAUTION

This function is only active in control mode. In the event of a power supply failure (electric or pneumatic), and in manual mode, the mechanical end positions are approached.

- Do not reach into the adjustment mechanism.

NOTE

The operating range must be greater than 10% of the sensor range.

NOTE

The display of the positioner in operating modes 1.0 through 1.2 always refers to the configured working range and indicates the position in %.

3.7.2 MAX_RGE – Operating range max.



The working range can be configured to be smaller than the maximum mechanical working range.

The setpoint range always refers to the configured working range. Use this parameter to specify the upper limit of the working range.

CAUTION

This function is only active in control mode. In the event of a power supply failure (electric or pneumatic), and in manual mode, the mechanical end positions are approached.

- Do not reach into the adjustment mechanism.

NOTE

The operating range must be greater than 10% of the sensor range.

NOTE

The display of the positioner in operating modes 1.0 through 1.2 always refers to the configured working range and indicates the position in %.

3.7.3 ZERO_POS – Zero position



With this parameter you can assign the zero position of the display to the zero position of the valves and fittings. It also allows you to select the direction of rotation of the sensor shaft (looking at the open housing).

i NOTE

Normally, the zero position is determined automatically and saved during standard Autoadjust.

Linear actuators	→ "counterclockwise"
Rotary actuators	→ "clockwise"

Selection

CLOCKW	Limit stop reached turning clockwise
CTCLOCKW	Limit stop reached turning counterclockwise

3.7.4 EXIT – Return to operating level



With this parameter you can leave the configuration level. The positioner returns to the operating level. Here you can either save data in the non-volatile memory or discard all previously made changes (also the changes in other parameter groups).

To leave the configuration level (with or without saving), press and hold **ENTER** until the countdown from 3 to 0 is finished.

The active saving process is indicated by the message **NV_SAVE**. After saving a plausibility check is executed.

If an error occurs during the check or while saving, the data cannot be saved and an error message is displayed instead (see Chapter "Error codes" on page 33).

Selection

NV_SAVE	Saves settings in the non-volatile memory.
CANCEL	Discards all changes made since the last permanent save operation.

3.8 Parameter group 4: Messages



3.8.1 TIME_OUT – Dead band time limit



With this parameter you enter the monitoring time until reaching the setpoint.

When the tolerance band is exceeded, the monitoring time is started. If the tolerance band within the predefined time is again not reached by the new position setpoint, an alarm is triggered.

(Parameter **TIME_OUT** in parameter group 5 must be activated.)

! CAUTION

With active shutdown function there is no alarm message.

Once the setpoint has been reached, the alarm is automatically reset.



i NOTE

The stroke time to be monitored should be 1.5 to 2x greater than the shortest stroke time selected during automatic adjustment.

Press and hold the **ENTER** button to display the stroke time. Press **ENTER** again to toggle between UP stroke time and DOWN stroke time.

3.8.2 POS_SW1 – Switching point SW1



With this parameter you can define the switching point SW1 as a percentage of the operating range.

If the position is above or below SW1, the corresponding signal output on the plug-in module is activated (see also parameter group **DIG_OUT** on page 29).

i NOTE

Changing the operating range also changes the positions of the switching points with respect to the position of the valves and fittings.

3.8.3 POS_SW2 – Switching point SW2



With this parameter you can define the switching point SW2 as a percentage of the operating range.

If the position is above or below SW2, the corresponding signal output on the plug-in module is activated (see also parameter group **DIG_OUT** on page 29).

i NOTE

Changing the operating range also changes the positions of the switching points with respect to the position of the valves and fittings.

3.8.4 SW1_ACTV – Active direction SW1



With this parameter you define whether a message is to be triggered for exceeding or falling below switching point SW1.

EXCEED	Message when exceeding switching point SW1.
FALL_BEL	Message when falling below switching point SW1.

3.8.5 SW2_ACTV – Active direction SW2



With this parameter you define whether a message is to be triggered for exceeding or falling below switching point SW2.

EXCEED	Message when exceeding switching point SW2.
FALL_BEL	Message when falling below switching point SW2.

3.8.6 EXIT – Return to operating level



With this parameter you can leave the configuration level. The positioner returns to the operating level. Here you can either save data in the non-volatile memory or discard all previously made changes (also the changes in other parameter groups).

To leave the configuration level (with or without saving), press and hold **ENTER** until the countdown from 3 to 0 is finished.

The active saving process is indicated by the message **NV_SAVE**. After saving a plausibility check is executed.

If an error occurs during the check or while saving, the data cannot be saved and an error message is displayed instead (see Chapter "Error codes" on page 33).

Selection	
NV_SAVE	Saves settings in the non-volatile memory.
CANCEL	Discards all changes made since the last permanent save operation.

3.9 Parameter group 5: Alarms



i NOTE

Active alarms are signaled at the digital output and using the "Analog feedback" option.

3.9.1 LEAKAGE – Leakage at actuator



If the monitoring function detects leakage at the actuator, a message is issued via alarm output on the mainboard.

ACTIVE	Monitoring active.
INACTIVE	Monitoring inactive.

3.9.2 SP_RGE – Setpoint monitoring



With this parameter, you can determine that a corresponding alarm is signaled via the digital output when falling below or exceeding the setpoint range (<3.8 mA or above 20.5 mA).

ACTIVE	Setpoint monitoring active.
INACTIVE	Setpoint monitoring inactive.

3.9.3 SENS_RGE – Operating range exceeded



With this parameter you can determine that an alarm is signaled via the digital output when the configured operating range is exceeded by 4%. (Position < -4 % or > 104 %). This may indicate improperly adjusted mounting or mechanical wear in a limit stop.

ACTIVE	Alarm active.
INACTIVE	Alarm not active.

3.9.4 CTRLER – Controller inactive



You can use this parameter to specify signaling of an alarm via a digital output if the positioner is not active, i.e., if the control mode is interrupted by another operating mode or by configuration.

i NOTE

For details of which statuses lead to a message, see see Chapter "Alarm codes" on page 35.

ACTIVE	Alarm active.
INACTIVE	Alarm not active.

3.9.5 TIME_OUT – Dead band time limit



Use this parameter to activate the "Dead band time limit" function.

The alarm is issued via digital output when the setpoint within the specified monitoring time is not reached in control mode. (The monitoring time is entered with parameter group 4, „TIME_OUT“.) The function is only active in control modes **ACTUATOR** and **AUTO_ADJ.**

ACTIVE	Dead band time limit is activated.
INACTIVE	Alarm not active.

3.9.6 STRK_CTR – Movement counter



With this parameter you can determine that an alarm is signaled when the movement counter exceeds the specified limit value. The limit value is edited remotely via PC.

ACTIVE	Alarm for exceeding travel counter limit value
INACTIVE	No Alarm

3.9.7 TRAVEL – Travel counter



With this parameter you can determine that an alarm is signaled when the travel counter exceeds the specified limit value. The limit value is edited remotely via PC.

ACTIVE	Alarm for exceeding movement counter limit value
INACTIVE	No Alarm

3.9.8 EXIT – Return to operating level



With this parameter you can leave the configuration level. The positioner returns to the operating level. Here you can either save data in the non-volatile memory or discard all previously made changes (also the changes in other parameter groups).

To leave the configuration level (with or without saving), press and hold **ENTER** until the countdown from 3 to 0 is finished.

The active saving process is indicated by the message **NV_SAVE**. After saving a plausibility check is executed.

If an error occurs during the check or while saving, the data cannot be saved and an error message is displayed instead (see Chapter "Error codes" on page 33).

Selection	
NV_SAVE	Saves settings in the non-volatile memory.
CANCEL	Discards all changes made since the last permanent save operation.

3.10 Parameter group 6: Manual adjustment



3.10.1 MIN_VR – Operating range min.



Normally, the operating range is determined automatically during Autoadjust. A partial run of automatic adjustment that is limited to the controller parameters (**CTRL_PAR**, see parameter **DANG_DN** on page 23) or valves and fittings without end stops, however, requires manual adjustment of the operating range.

⚠ CAUTION

Risk of injury!
After manual adjustment of the end positions, it is essential to limit the operating range to > 0.1 and < 99.9 under **MIN_RGE** and **MAX_RGE**. Otherwise, the valves and fittings may be driven at full speed to an end position.
– Do not reach into the adjustment mechanism.

The range between high and low limit value must be at least 10% of the full range. Otherwise, the message **VR< 10 %** is displayed.

i NOTE

Use as large are range as possible. This parameter is not active when the safe position is active. The display then shows the message **FAIL_POS**.

Use **MIN_VR** to determine the lower limit of the operating range.

↑ or ↓	Press in order to travel to the desired position.
ENTER	Press and hold until the countdown has completed (MIN_SET). The position is saved as the minimum limit value.
ENTER	Press briefly. The set limit value is displayed for 2 seconds (MIN_SAVE).

3.10.2 MAX_VR – Operating range max.



Normally, the operating range is determined automatically during Autoadjust. A partial run of automatic adjustment that is limited to the controller data (**STANDARD**, see parameter **ADJ_MODE** on page 12) or valves and fittings without end stops, however, requires manual adjustment of the operating range.

⚠ CAUTION

Risk of injury!

After manual adjustment of the end positions, it is essential to limit the operating range to > 0.1 and < 99.9 under **MIN_RGE** and **MAX_RGE**. Otherwise, the valves and fittings may be driven at full speed to an end position.

- Do not reach into the adjustment mechanism.

The range between high and low limit value must be at least 10% of the full range. Otherwise, the message **VR< 10 %** is displayed.

i NOTE

Use as large are range as possible. This parameter is not active when the safe position is active. The display then shows the message **FAIL_POS**.

Use **MAX_VR** to determine the upper limit of the operating range.

↑ or ↓	Press in order to travel to the desired position.
ENTER	Press and hold until the countdown has completed (MIN_SET). The position is saved as the minimum limit value.
ENTER	Press briefly. The set limit value is displayed for 2 seconds (MIN_SAVE).

3.10.3 ACTUATOR – Actuator type



With this parameter you can configure the positioner for operation on a linear actuator (sensor range $\pm 30^\circ$) or on a part-turn actuator (sensor range $\pm 45^\circ$). No mechanical modifications to the positioner are required.

i NOTE

After changing the actuator type, it is recommended that you run Auto Adjust to prevent linearity errors.

Selection

LINEAR	Linear actuator
ROTARY	Part-turn actuator

3.10.4 SPRNG_Y2 – Spring action (Y2)



⚠ CAUTION

Risk of injury!

Incorrect entries may result in the actuator traveling to a mechanical stop at full speed.

Use this parameter to specify the end position to which the reset spring of the pneumatic actuator drives the valves and fittings in the event that the power supply fails.

The corresponding end stop is determined during Autoadjust. If, however, only the controller data are determined (**STANDARD**, see parameter **ADJ_MODE**), the spring action must be entered manually.

Select the direction of rotation of the sensor shaft (looking at the open housing) for when the safe position is approached as a result of the spring force (actuator exhausts via **OUT1**). For double-acting actuators, the spring action has the same effect as ventilating the pneumatic output **OUT2**.

CLOCKW	Stop reached turning clockwise
CTCLOCKW	Stop reached turning counterclockwise

3.10.5 DANG_DN – Dead Angle Close



Use this parameter to cut off the unusable range of the valve flow characteristic curve from the point of view of control. The **Dead Angle Close** is a percentage of the operating range to which the valve is moved if the input signal is 4.16 mA.

3.10.6 DANG_UP – Dead Angle Open



Use this parameter to cut off the unusable range of the valve flow characteristic curve from the point of view of control. The **Dead Angle Open** is a percentage of the operating range to which the valve is moved if the input signal is 19.84 mA.

3.10.7 BOLT_POS – Actuator position



The installation type of the actuator bolt for the potentiometer has a decisive influence on the linearization of the potentiometer signal.

Using the function BOLT_POS, this installation type is taken into account in the algorithm. The following options can be selected:

- STEM (actuator bolt on the valve spindle)
- LEVER (actuator bolt on the potentiometer lever)

For detailed information about the position of the actuator bolt, see the operating instructions.

3.10.8 EXIT – Return to operating level



With this parameter you can leave the configuration level. The positioner returns to the operating level. Here you can either save data in the non-volatile memory or discard all previously made changes (also the changes in other parameter groups).

To leave the configuration level (with or without saving), press and hold **ENTER** until the countdown from 3 to 0 is finished.

The active saving process is indicated by the message **NV_SAVE**. After saving a plausibility check is executed.

If an error occurs during the check or while saving, the data cannot be saved and an error message is displayed instead (see Chapter "Error codes" on page 33).

Selection	
NV_SAVE	Saves settings in the non-volatile memory.
CANCEL	Discards all changes made since the last permanent save operation.

3.11 Parameter group 7: Control parameters



3.11.1 KP UP – KP value (up)



i NOTE

In the case of most actuators, all control parameters can be optimized by using Auto Adjust. Changes should only be made when auto adjust cannot be executed or control stability cannot be achieved.

The KP value is the gain of the controller. The control speed and stability are influenced by the KP value. With higher KP values, the control speed increases.

i NOTE

The control precision is not affected by the KP value.

To compensate for existing dissymmetries in the controlled system, the KP value should be set separately for both positioning directions (up / down).

For most actuators, a satisfactory control response is achieved with a KP value in the 2.0 ... 10.0 range. Use the parameter **KP UP** to adjust the KP value for the upward positioning direction (towards 100 %).

3.11.2 KP DN – KP value (down)



i NOTE

In the case of most actuators, all control parameters can be optimized by using Auto Adjust. Changes should only be made when auto adjust cannot be executed or control stability cannot be achieved.

The KP value is the gain of the controller. The control speed and stability are influenced by the KP value. With higher KP values, the control speed increases.

i NOTE


The control precision is not affected by the KP value.

To compensate for existing asymmetries in the controlled system, the KP value should be set separately for both positioning directions (up / down).

For most actuators, satisfactory control behavior is achieved with a KP value between 2.0 ... 10.0.

Use the **KP DN** parameter to adjust the KP value for the downward positioning direction (towards 0 %).

3.11.3 TV UP – TV value (up)



i NOTE

In the case of most actuators, all control parameters can be optimized by using Auto Adjust. Changes should only be made when auto adjust cannot be executed or control stability cannot be achieved.

The TV value is the derivative time of the controller.

The control speed and stability are affected by the TV value in such a way that it counteracts the KP value dynamically. The control speed decreases as the TV value increases.

To compensate for existing dissymmetries in the controlled system, the TV value should be configured separately for both positioning directions (up / down).

Use the **TV UP** parameter to adjust the TV value for the upward positioning direction (towards 100 %).

3.11.4 TV DN – TV value (down)



i NOTE

In the case of most actuators, all control parameters can be optimized by using Auto Adjust. Changes should only be made when auto adjust cannot be executed or control stability cannot be achieved.

The TV value is the derivative time of the controller. Control speed and stability are affected by the TV value in terms of how this dynamically counteracts the KP value. The control speed decreases as the TV value increases.

To compensate for existing asymmetries in the controlled system, the TV value should be configured separately for both positioning directions (up / down).

Use the **TV DN** parameter to adjust the TV value for the downward positioning direction (towards 0 %).

3.11.5 Y-OFS UP – Y offset (up)



i NOTE

In the case of most actuators, all control parameters can be optimized by using Auto Adjust. Changes should only be made when auto adjust cannot be executed or control stability cannot be achieved.

The "offset for the setpoint signal" linearizes the behavior of the I/P module used and enables rapid compensation even in the case of small control deviations. The value is limited at the lower end by a minimum value (neutral zone).

The offset significantly affects the control speed for control deviations of less than 5 %.

In manual modes **MANUAL** and **MAN_SENS**, the offset values are issued to the I/P module for fine adjustment. With larger, slower actuators, Autoadjust may determine offset values higher than 80 %. In these cases there will be no noticeable difference between fine and coarse adjustment while in manual mode.


To compensate for existing asymmetries in the controlled system, the offset should be configured separately for both positioning directions (up / down).

For most actuators, satisfactory control behavior is achieved with offset values between 40 ... 80 %. If, in the event of setpoint changes, the control behavior demonstrates an overshoot of less than 2 %, both offset values should be decreased.

Both offset values should be increased when the actuator stops outside the tolerance band.

Use the parameter **Y-OFS UP** to adjust the Y offset for the upward positioning direction (towards 100 %).

3.11.6 Y-OFS DN – Offset (down)



i NOTE

In the case of most actuators, all control parameters can be optimized by using Auto Adjust. Changes should only be made when auto adjust cannot be executed or control stability cannot be achieved.

The "offset for the setpoint signal" linearizes the behavior of the I/P module used and enables rapid compensation even in the case of small control deviations. The value is limited at the lower end by a minimum value (neutral zone).

The offset significantly affects the control speed for control deviations of less than 5 %.

In manual modes **MANUAL** and **MAN_SENS**, the offset values are issued to the I/P module for fine adjustment. For larger, slower actuators Autoadjust may determine values higher than 80 %. In these cases there will be no noticeable difference between fine and coarse adjustment while in manual mode.

To compensate for existing asymmetries in the controlled system, the offset should be configured separately for both positioning directions (up / down).

For most actuators, a satisfactory control response is achieved with offset values in the 40 ... 80 % range. If, in the event of setpoint changes, the control behavior demonstrates an overshoot of less than 2 %, both offset values should be decreased.

Both offset values should be increased when the actuator stops outside the tolerance band.

Use the parameter **Y-OFS DN** to adjust the Y offset for the downward positioning direction (towards 0 %).

3.11.7 TOL_BAND – Tolerance band



The "tolerance band" **TOL_BAND** defines a \pm range around the position setpoint. When the position of the valves and fittings reaches this range, the parameter set of the positioner is toggled to a different algorithm that is used to continue with a slow controlling action until the dead band **DEADBAND** is reached.

The system is only considered balanced once the sensitivity range is reached (see parameter **ADJ_MODE** on page 12.)

Input value	in steps of 0.1 %
-------------	-------------------

3.11.8 DEADBAND – Dead band



The "dead band" **DEADBAND** defines a \pm range around the position setpoint. Once the valves and fittings reach this range, the positioner maintains this position.

i NOTE

The dead band must always be 0.2% less than the tolerance band.

Input value	in steps of 0.01 %
-------------	--------------------

3.11.9 DB_APPR – Dead band approach



The **DB_APPR** parameter specifies the speed at which the dead band is approached.

In rare cases, overshooting can occur when the valve position is being compensated. This can be prevented by reducing the speed of the dead-band approach.

TEST – Test



The test is used to activate the controller, and you can check the effects of the changes to this parameter group, e.g., by introducing setpoint changes or setpoint ramps using a current source.


Normally, **INACTIVE** is shown in the display. To start the test, press and hold **ENTER** until the countdown from 3 to 0 is finished. The test is activated. The display shows the control loop symbol and a flashing message.

The test is automatically stopped after two minutes and can also be stopped by pressing any button.

i NOTE

It is not possible to activate the test when the safe position is active (see parameter **FAIL_POS** on page 31). Instead, the message **FAIL_POS** is displayed.

3.11.10 DB_CALC – Dead-band determination



In standard automatic adjustment, the algorithm determines the dead band as well as the end positions and control parameters. In some applications, you may need to perform a new automatic adjustment after installation in the system, but to leave the dead band at a preset value.

DB_CALC offers the following setting options:

- ON (automatic adjustment with dead band determination)
- OFF (automatic adjustment without dead band determination)

3.11.11 LEAK_SEN – Leakage sensitivity



Determination of a possible leakage between the output positioner and the pneumatic actuator. If the valve position moves out of the dead zone (dead band) in the same direction seven times in succession within a defined time range, there is a high probability of a leakage in the connecting lines between the positioner and the pneumatic actuator. **LEAK_SEN** enables you to define the time range within which the valve may leave the dead band a maximum of seven times in succession before an alarm is generated. You can choose a time range of between 1 and 7200 seconds.

3.11.12 EXIT – Return to operating level



With this parameter you can leave the configuration level. The positioner returns to the operating level. Here you can either save data in the non-volatile memory or discard all previously made changes (also the changes in other parameter groups).

To leave the configuration level (with or without saving), press and hold **ENTER** until the countdown from 3 to 0 is finished.

The active saving process is indicated by the message **NV_SAVE**. After saving a plausibility check is executed.

If an error occurs during the check or while saving, the data cannot be saved and an error message is displayed instead (see Chapter "Error codes" on page 33).

Selection	
NV_SAVE	Saves settings in the non-volatile memory.
CANCEL	Discards all changes made since the last permanent save operation.

3.12 Parameter group 8: Analog output (on the plug-in module for analog feedback)



3.12.1 MIN_RGE – Current range min.



Use this parameter to specify the lower current range limit for the analog feedback. The current range corresponds to the configured stroke range.

i NOTE

The current range limits can be freely configured between 4 ... 18.5 mA. However, the current range must not be smaller than 10 % (1.6 mA).

3.12.2 MAX_RGE – Current range max.



Use this parameter to specify the upper current range limit for the analog feedback.

i NOTE

The current range limits can be freely configured between 4 ... 20 mA. However, the current range must not be smaller than 10 % (1.6 mA).

3.12.3 ACTION – Characteristic curve action



Use this parameter to specify the characteristic curve for the analog feedback.

Increasing	Position 0 ... 100 % = Signal 4 ... 20 mA
Decreasing	Position 0 ... 100 % = Signal 20 ... 4 mA

3.12.4 ALARM – Alarm



When an alarm / message is generated in the positioner, it is signaled via the digital and analog outputs. You can use the **ALARM** parameter to select a higher or lower alarm current for analog feedback.

i NOTE

Without electrical power or during initialization the output signal is > 20.5 mA. A special version (hardware change) is also available, with which a value of < 3.8 mA is also possible.

HIGH_CUR	Alarm current I > 20.5 mA
LOW_CUR	Alarm current I < 3.8 mA

3.12.5 RB_CHAR – Count back characteristic curve



You can use this parameter to determine whether the position indicator and the analog position feedback follow the characteristic curve set in parameter **CHARACT** - Characteristic curve.

3.12.6 TEST – Test



Test is for simulation of the analog output. The test allows you to simulate effects during commissioning without affecting the normal process.

i NOTE

The test is automatically stopped after two minutes. While the test is running, the corresponding message (see below) flashes in the display.

NONE	No function
FAILED	Simulation of position feedback failure (CPU). I > 20.5 mA (standard) or I < 3.8 mA (special version, changed hardware)
ALRM_CUR	Simulation of an alarm current < 3.8 mA or I > 20.5 mA
CURRENT	Output of the current setpoint as current value via analog output. All configurations and settings of the analog input and / or output must be taken into consideration.

3.12.7 ALR_ENAB – Alarm via analog output



Enables the alarm signal to be switched on / off using the optional analog output module.
Selection option: **ON / OFF**.

3.12.8 CLIPPING – Extending the signal output range



Enables extension of the permissible signal output range to 3.8 ... 20.5 mA.

Selection option:
– 4.0 ... 20.0 mA
– 3.8 ... 20.5 mA

3.12.9 EXIT – Return to operating level



With this parameter you can leave the configuration level. The positioner returns to the operating level. Here you can either save data in the non-volatile memory or discard all previously made changes (also the changes in other parameter groups).

To leave the configuration level (with or without saving), press and hold **ENTER** until the countdown from 3 to 0 is finished.

The active saving process is indicated by the message **NV_SAVE**. After saving a plausibility check is executed.

If an error occurs during the check or while saving, the data cannot be saved and an error message is displayed instead (see Chapter "Error codes" on page 33).

Selection	
NV_SAVE	Saves settings in the non-volatile memory.
CANCEL	Discards all changes made since the last permanent save operation.

3.13 Parameter group 9: digital output



3.13.1 ALRM_LOG – Alarm output logic

i NOTE

SW1 and SW2 are on the plug-in module for digital feedback



With this parameter you can determine the logic level of the alarm output.

Selection

ACTIV_HI	active = output current $I > 2$ mA
ACTIV_LO	active = output current $I < 1$ mA

3.13.2 SW1_LOG – Logic



You can use this parameter to define the active state for switch output SW1 (on the plug-in module for digital feedback).

Selection

ACTIV_HI	active = output current $I > 2$ mA
ACTIV_LO	active = output current $I < 1$ mA

3.13.3 SW2_LOG – Logic



You can use this parameter to define the active state for switch output SW2 (on the plug-in module for digital feedback).

Selection

ACTIV_HI	active = output current $I > 2$ mA
ACTIV_LO	active = output current $I < 1$ mA

TEST – Test



Test is for simulation for the digital output.


i NOTE

The test is automatically stopped after two minutes and can be aborted by pressing any button.

While the test is running, the corresponding message (see below) flashes in the display.

NONE	No function
ALRM_ON	Alarm is simulated (DO active)
SW1_ON	Reaching switching point 1 is simulated (SW1 active)
SW2_ON	Reaching switching point 2 is simulated (SW2 active)
ALL_ON	Alarm and switching points are simulated (all DOs active)

3.13.4 EXIT – Return to operating level



With this parameter you can leave the configuration level. The positioner returns to the operating level. Here you can either save data in the non-volatile memory or discard all previously made changes (also the changes in other parameter groups).

To leave the configuration level (with or without saving), press and hold **ENTER** until the countdown from 3 to 0 is finished.

The active saving process is indicated by the message **NV_SAVE**. After saving a plausibility check is executed.

If an error occurs during the check or while saving, the data cannot be saved and an error message is displayed instead (see Chapter "Error codes" on page 33).

Selection

NV_SAVE	Saves settings in the non-volatile memory.
CANCEL	Discards all changes made since the last permanent save operation.

3.14 Parameter group 10: digital input



3.14.1 FUNCTION – Digital input function selection



For the digital input, one of the following protective functions can be selected via local operation.

- No function (default)
- Move to 0 % position
- Move to 100 % position
- Hold previous position
- Disable local configuration.
- Disable local configuration and operation
- Disable all access (local or via PC)

The selected function is activated when the 24 V signal is no longer connected to the digital output (< 10 V DC).

The safety functions **POS_0 %**, **POS_100 %** and **POS_HOLD** are executed on the operating level in both control operating modes **P1.0** or **P1.1**. **BIN_CTRL** is shown in the display.

If a corresponding function is active, a corresponding value is defined internally for the positioner. The actuator is then driven into the end position or position specified under consideration of the set point ramp, configured operating range, selected behavior etc.

After selecting an operation lock **CNF_LOCK**, **OP_LOCK** or **ALL_LOCK**, the key icon is displayed, indicating that the operation lock will be activated at the next save.

After saving and without 24V at the digital input, the key is permanently displayed.

i NOTE

The operation lock **CNF_LOCK**, **OP_LOCK** or **ALL_LOCK** is displayed only if the voltage is connected to the digital input.

CNF_LOCK	Local access to the configuration level is inhibited. However, local operation on the operating level is possible. The positioner can be configured externally (via LCI / modem and PC). When the operator tries to activate the configuration level, the text CNF_LOCK is displayed for approx. 5 seconds.
OP_LOCK	Local operation and configuration is completely inhibited. With every attempt to perform local operating actions, the message OP_LOCK is shown for approx. 5 seconds.

i NOTE

The positioner can be configured externally (via LCI / modem and PC).

ALL_LOCK	Local operation (operating level and configuration level) and external configuration via LCI / modem and PC are inhibited. With every attempt to perform local operating actions, the message ALL_LOCK is shown for approx. 5 seconds.
-----------------	---

3.14.2 EXIT – Return to operating level



With this parameter you can leave the configuration level. The positioner returns to the operating level. Here you can either save data in the non-volatile memory or discard all previously made changes (also the changes in other parameter groups).

To leave the configuration level (with or without saving), press and hold **ENTER** until the countdown from 3 to 0 is finished.

The active saving process is indicated by the message **NV_SAVE**. After saving a plausibility check is executed.

If an error occurs during the check or while saving, the data cannot be saved and an error message is displayed instead (see Chapter "Error codes" on page 33).

Selection	
NV_SAVE	Saves settings in the non-volatile memory.
CANCEL	Discards all changes made since the last permanent save operation.

3.15 Parameter group 11: Safe position



3.15.1 FAIL_POS – Safe position



This parameter must be used to activate the safe position prior to loading the factory settings (parameter **FACT_SET**) or changing the I/P module type (parameter **IIP-TYP**).

i NOTE

After setting parameters **FACT_SET** and **IIP-TYP** as required, the safe position must be deactivated again manually.

The safe position that is activated (i.e., whether the actuator is ventilated or blocked) depends on the I/P module installed.

Activating / deactivating the safe position:

Press and hold **ENTER** until the displayed countdown from 3 to 0 is finished. Then release **ENTER**.

The safe position is activated or deactivated, respectively.

3.15.2 FACT_SET – Factory setting



You can use this parameter to reset the positioner to the factory setting. This is necessary, e.g., if an already configured positioner has to be installed on a different actuator and subsequently reconfigured.

⚠ CAUTION

Risk of injury!

For safety reasons, after loading the factory settings you must check whether the I/P module type that is set matches the actual I/P module type present in the device.

Otherwise dangerous situations may occur when operating in control mode. It may happen that the actuator is driven at full speed to the end position.

i NOTE

You can only load the factory settings when the actuator is in the safe position (parameter **FAIL_POS**). Otherwise, this action is inhibited and the message **NO_F_POS** is indicated in the display.

If you save the settings in the non-volatile memory after loading the factory settings, operating mode 1.3 is automatically activated on the operating level.

Load factory settings:

Press and hold **ENTER** until the displayed countdown from 3 to 0 is finished.

The positioner is reset to the factory settings. The message **COMPLETE** is displayed.

Press **ENTER** to acknowledge the message.

Selection

FS_LOAD	Loads the factory settings
----------------	----------------------------

3.15.3 IP-TYP – Type of the I/P module



Use this parameter to adapt the positioner software to the installed I/P module. This is required when installing a different I/P module type.

CAUTION

Risk of injury!

For safety reasons, after loading the factory settings you must check whether the I/P module type that is set matches the actual I/P module type present in the device. Otherwise dangerous situations may occur when operating in control mode. It may happen that the actuator is driven at full speed to the end position.

CAUTION

For safety reasons, after restoring the positioner to the factory settings you must check whether this parameter has been correctly set.

3.15.4 IP_COMP – IP Compensation



This function is reserved for use by ABB Service only.

3.15.5 HART_REV – HART version



As of firmware version 5, the positioner offers communication via both standard HART 5 and HART 7. To select, use the arrow keys **↑** or **↓**.

Squawk command:

A standardized HART-7 command causes the bottom menu line in the HMI of the addressed device to flash. This visual aid makes it easier to identify the addressed device in the system.

3.15.6 EXIT – Return to operating level



With this parameter you can leave the configuration level. The positioner returns to the operating level. Here you can either save data in the non-volatile memory or discard all previously made changes (also the changes in other parameter groups).

To leave the configuration level (with or without saving), press and hold **ENTER** until the countdown from 3 to 0 is finished.

The active saving process is indicated by the message **NV_SAVE**. After saving a plausibility check is executed.

If an error occurs during the check or while saving, the data cannot be saved and an error message is displayed instead (see Chapter "Error codes" on page 33).

Selection

NV_SAVE	Saves settings in the non-volatile memory.
CANCEL	Discards all changes made since the last permanent save operation.

4 Diagnosis / error messages

4.1 Error codes

Error code	Possible cause	Impact	Troubleshooting the Instrument
ERROR 10	The supply voltage was interrupted for at least 20 ms. (This error is displayed after resetting the device to indicate the reason for the reset.)	-	Check the power source and the wiring.
ERROR 11	The supply voltage has fallen below the minimum voltage.	The actuator is moved to the safe position. After approx. 5 seconds, the positioner is automatically reset and starts up again with the message ERROR 10 . If a local communication interface (LCI) is plugged in, the device will enter the operating mode LCI supply.	Check the power source and the wiring.
ERROR 12	The position is outside the measuring range. Possible reason is a malfunction in the position sensor.	In control mode: The actuator is moved to the safe position. On the configuration level: The output is set to neutral until a button is pressed. After approx. 5 seconds the positioner is automatically reset in control mode and on the configuration level.	Check the mounting.
ERROR 13	Invalid input current. This display indicates when the setpoint signal is overridden. The actuator is moved to the safe position.	-	Check the power source and the wiring.
ERROR 20	No access possible to the data in the EEPROM.	The actuator is moved to the safe position. After approx. 5 seconds, the positioner is automatically reset. Attempts are made to restore the data. This compensates for intermittent errors in the communication environment with the EEPROM.	If there is still no access to the EEPROM data after resetting the device, load the factory settings. If the error still persists, the device must be returned for repair to the manufacturer.

Error code	Possible cause	Impact	Troubleshooting the Instrument
ERROR 21	Error while processing the measured values, pointing to an error in the working data (RAM).	The actuator is moved to the safe position. After approx. 5 seconds, the positioner is automatically reset and the RAM is reinitialized.	If the error persists even after the positioner has been reset, the device will need to be returned to the manufacturer for repair.
ERROR 22	Error during the table processing, pointing to an error in the working data (RAM).	The actuator is moved to the safe position. After approx. 5 seconds, the positioner is automatically reset and the RAM is reinitialized.	If the error persists even after the positioner has been reset, the device will need to be returned to the manufacturer for repair.
ERROR 23	Error when verifying the checksum of the configuration data (RAM).	The actuator is moved to the safe position. After approx. 5 seconds, the positioner is automatically reset and the RAM is reinitialized.	If the error persists even after the positioner has been reset, the device will need to be returned to the manufacturer for repair.
ERROR 24	Error in the processor function registers (RAM).	The actuator is moved to the safe position. After approx. 5 seconds, the positioner is automatically reset and the RAM is reinitialized.	If the error persists even after the positioner has been reset, the device will need to be returned to the manufacturer for repair.
ERROR 50 ⋮ ERROR 99	Internal error.	The actuator is moved to the safe position. After approx. 5 seconds, the positioner is automatically reset.	If the error can be reproduced and occurs in the same position after resetting, the device must be returned for repair to the manufacturer.

4.2 Alarm codes


Alarm code	Possible cause	Impact	Troubleshooting the Instrument
ALARM 1	Leakage between positioner and actuator	Depending on how well the leakage can be compensated, small control actions are required at regular intervals.	Check the piping.
ALARM 2	The setpoint current is outside the permissible range, i.e. it is < 3.8 mA or > 20.5 mA.	-	Check the power source.
ALARM 3	Alarm of the zero monitor. The zero position has shifted by more than 4%.	- In control mode, a position outside the valve range can only be reached by driving to the limit stops, as the setpoint is limited to 0 ... 100%.	Correct the mounting.
ALARM 4	Controlling is inactive, because the device does not operate in control mode or the binary input is active.	The controller does not follow the setpoint.	Switch to control mode or switch off the binary input.
ALARM 5	Positioning timed out. The settling time needed exceeds the configured stroke time.	None, or adaptive control is performed (in adaptive mode).	Ensure that <ul style="list-style-type: none"> – the actuator is not blocked. – the supply air pressure is adequate. – the given time limit is higher than 1.5 times the longest stroke time of the actuator. If adaption cannot run uninterruptedly for an actuator, adaption should be switched on until the alarm does not occur anymore during controlling actions.
ALARM 6	The defined limit value for the stroke counter has been exceeded.	-	Reset the counter (only possible via a connected PC with suitable software).
ALARM 7	The specified limit value for the travel counter has been exceeded.	-	Reset the counter (only possible via a connected PC with suitable software).

4.3 Message codes


Message codes	Message description
BREAK	Action stopped by operator.
CALE_ERR	Error during plausibility check.
COMPLETE	Action completed, acknowledgment required.
EEPROM_ERR	Memory error, data could not be saved.
FAIL_POS	Safe position is active, action cannot be executed.
NO_F_POS	Safe position required, but not active.
NO_SCALE	Valve range limits have not yet been determined; therefore, partial Autoadjust cannot be run.
NW_SAVE	Data is saved in the non-volatile memory.
OUTOFRNG	Measuring range is exceeded, Auto Adjust was automatically stopped.
LOAD	Data (factory settings) are being loaded.
RNG_ERR	Less than 10 % of the measuring range is used.
RUN	Action running.
SIMUL	Simulation has been started externally from a PC via HART, Protocol; switching outputs, alarm output and analog position feedback are no longer influenced by the process.
SPR_ERR	Actual spring action is different from the adjusted one.
TIMEOUT	Time-out; parameter could not be determined within two minutes; Autoadjust was automatically stopped.

4.4 Error handling

4.4.1 Positioner vibrates



4.4.2 Positioner without function



Notes

Contact us

ABB Limited

Process Automation

Howard Road, St. Neots
Cambridgeshire, PE19 8EU
UK

Tel: +44 (0)870 600 6122

Fax: +44 (0)1480 213 339

Mail: enquiries.mp.uk@gb.abb.com

ABB Inc.

Process Automation

125 E. County Line Road
Warminster, PA 18974
USA

Tel: +1 215 674 6000

Fax: +1 215 674 7183

ABB Automation Products GmbH

Process Automation

Schillerstr. 72
32425 Minden
Germany

Tel: +49 571 830-0

Fax: +49 571 830-1806

www.abb.com/positioners

Note

We reserve the right to make technical changes or modify the contents of this document without prior notice.

With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents in whole or in parts – is forbidden without prior written consent of ABB.

Copyright© 2016 ABB

All rights reserved

3KXE341209R4501

Original instruction